

## CHAPTER Env-Wt 900 STREAM CROSSINGS; CERTIFIED CULVERT MAINTAINER PROGRAM

## PART Env-Wt 901 PURPOSE; APPLICABILITY; EXEMPTIONS; INCORPORATED DEFINITIONS

- Env-Wt 901.01 Purpose
- Env-Wt 901.02 Applicability
- Env-Wt 901.03 Exemptions
- Env-Wt 901.04 Incorporated Definitions

## PART Env-Wt 902 DEFINITIONS

- Env-Wt 902.01 “Aggradation”
- Env-Wt 902.02 “Aquatic organism”
- Env-Wt 902.03 “Bankfull depth”
- Env-Wt 902.04 “Bankfull flow”
- Env-Wt 902.05 “Bankfull width”
- Env-Wt 902.06 “Closed-bottom culvert”
- Env-Wt 902.07 “Connectivity”
- Env-Wt 902.08 “Design storm”
- Env-Wt 902.09 “Embedded”
- Env-Wt 902.10 “Entrenchment ratio”
- Env-Wt 902.11 “Existing legal crossing”
- Env-Wt 902.12 “Flood-prone width”
- Env-Wt 902.13 “Geomorphic compatibility”
- Env-Wt 902.14 “Grade control”
- Env-Wt 902.15 “Hydraulic capacity”
- Env-Wt 902.16 “Longitudinal profile”
- Env-Wt 902.17 “Open-bottom culvert”
- Env-Wt 902.18 “Permanent crossing”
- Env-Wt 902.19 “Pipe arch”
- Env-Wt 902.20 “Reference reach”
- Env-Wt 902.21 “Rehabilitation”
- Env-Wt 902.22 “Repair”
- Env-Wt 902.23 “Replace in kind”
- Env-Wt 902.24 “Replacement”
- Env-Wt 902.25 “Self-mitigating”
- Env Wt 902.26 “Sinuosity”
- Env-Wt 902.27 “Span structure”
- Env-Wt 902.28 “Stream channel”
- Env-Wt 902.29 “Stream enhancement”
- Env-Wt 902.30 “Stream simulation”
- Env-Wt 902.31 “Temporary crossing”
- Env-Wt 902.32 “Tier 1 stream crossing”
- Env-Wt 902.33 “Tier 2 stream crossing”
- Env-Wt 902.34 “Tier 3 stream crossing”
- Env-Wt 902.35 “Tier 4 stream crossing”

## PART Env-Wt 903 STREAM CROSSINGS: CLASSIFICATIONS AND APPLICATIONS

- Env-Wt 903.01 Summaries of Stream Crossing Classifications and Projects
- Env-Wt 903.02 Classification of Stream Crossings and Stream Crossing Projects
- Env-Wt 903.03 Application Fees
- Env-Wt 903.04 Information Required for Stream Crossing SPNs, LSAs, and EXPs
- Env-Wt 903.05 Information Required for All Stream Crossing Standard Permit Applications
- Env-Wt 903.06 Information Required for Certain Stream Crossing Standard Permit Applications
- Env-Wt 903.07 Hydraulic Capacity Report

**PART Env-Wt 904 DESIGN AND CONSTRUCTION OF STREAM CROSSINGS**

- Env-Wt 904.01 General Design Considerations
- Env-Wt 904.02 Conditions Applicable to All Stream Crossing Work
- Env-Wt 904.03 Tier 1 Stream Crossings
- Env-Wt 904.04 Tier 2 Stream Crossings
- Env-Wt 904.05 Tier 3 Stream Crossings
- Env-Wt 904.06 Tier 4 Stream Crossings
- Env-Wt 904.07 Design Criteria for Tier 2, Tier 3, and Tier 4 Stream Crossings
- Env-Wt 904.08 Repair, Rehabilitation, or Replacement of Tier 1 or Tier 2 Existing Legal Stream Crossings
- Env-Wt 904.09 Repair, Rehabilitation, or Replacement of Tier 3 or Tier 4 Existing Legal Stream Crossings
- Env-Wt 904.10 Alternative Designs

**PART Env-Wt 905 CERTIFIED CULVERT MAINTAINER PROGRAM**

- Env-Wt 905.01 Applicability
- Env-Wt 905.02 Definitions
- Env-Wt 905.03 Qualifications for Initial Certificate
- Env-Wt 905.04 Application for Initial Certificate
- Env-Wt 905.05 Signature Required
- Env-Wt 905.06 Issuance of Certificate
- Env-Wt 905.07 Certificate Renewal; Continuing Education Required
- Env-Wt 905.08 Obligations and Responsibilities of Certified Individuals
- Env-Wt 905.09 Quarterly Reporting Required
- Env-Wt 905.10 Suspension, Revocation, or Refusal to Renew Certificate
- Env-Wt 905.11 Approved Provider Application
- Env-Wt 905.12 Designation as Approved Provider
- Env-Wt 905.13 Signature and Certification
- Env-Wt 905.14 Expiration and Renewal of Designation
- Env-Wt 905.15 Obligations of Approved Providers
- Env-Wt 905.16 Delegation of Certain Administrative Functions to Approved Providers