


# CyanoHABs Response Protocol for Public Water Supplies



*Microcystis aeruginosa*

**New Hampshire Department of Environmental Services  
Drinking Water and Groundwater Bureau  
29 Hazen Drive  
Concord, NH 03302**

# TABLE OF CONTENTS

INTRODUCTION .....	3
Contacting NHDES .....	3
Key terms used in the protocol .....	3
MONITORING .....	4
CyanoHABs Monitoring and Response Flowchart.....	5
Table 1: Common New Hampshire Cyanobacteria and Associated or Known Toxins .....	6
Table 2: Cyanotoxins and Common Modes of Action .....	7
LABORATORY METHODS .....	8
USEPA Methods for Cyanobacteria Toxin Analysis .....	8
USEPA Method 544: Determination of Microcystins and Nodularin in Drinking Water by Solid Phase Extraction and Liquid Chromatography/Tandem Mass Spectrometry (LC/MS/MS) .....	8
USEPA Method 545: Determination of Cylindrospermopsin and Anatoxin-a in Drinking Water by Liquid Chromatography Electrospray Ionization Tandem Mass Spectrometry (LC/ESI—MS/MS) .....	8
USEPA Method 546: Determination of Total Microcystins and Nodularins in Drinking Water and Ambient Water by ADDA—Enzyme—Linked Immunosorbent Assay (ADDA—ELISA) .....	8
Table 3: Labs Conducting LC/MS and ADDA—ELISA Toxin Analysis using USEPA Methods 544/545/546.....	9
SAMPLING .....	10
Safety Precautions.....	10
Recommended Safety Supplies .....	10
General Sampling Supplies .....	10
Analytical Method Specific Supplies.....	10
Sample Collection, Preservation, Shipment and Storage.....	11
Sample Collection Procedure for Grab Samples and Surface Skim Samples .....	11
Sample Collection Procedure for EPA Methods 544 and 545 .....	11
Sample Collection Procedure for EPA Method 546 .....	11
JCLC Sample Submittal Procedure.....	12

# INTRODUCTION

The following describes the New Hampshire Department of Environmental Services (NHDES) protocol for responding to suspected cyanobacteria harmful algal blooms (cyanoHABs) in public water supply sources. An overview of the protocol is provided in the attached flow chart. This protocol uses a tiered approach, with screening and monitoring steps, leading to actions including optimizing treatment and notifying the public if test results indicate that cyanotoxins are or may be present at levels of concern.

This describes the approach for water systems that are not already implementing a customized protocol developed in consultation with NHDES.

## Contacting NHDES

**Call in the following order in case of a suspected bloom.**

### **Jody Connor Limnology Center (JCLC):**

- [\(603\) 848-8094](tel:6038488094) (Cyanobacteria Bloom Hotline) – primary contact number for Cyanobacteria issues
- [\(603\) 271-0698](tel:6032710698) (Beach Coordinator office)
- [\(603\) 271-8865](tel:6032718865) (JCLC Director office)

### **Drinking Water and Groundwater Bureau (DWGB)**

- [\(603\) 271-2513](tel:6032712513) (8:00 AM – 4:00 PM weekdays except holidays)
- [\(603\) 223-4381](tel:6032234381) (New Hampshire State Police – outside NHDES business hours)

## Key terms used in the protocol:

- NHDES – New Hampshire Department of Environmental Services
- cyanoHABs – cyanobacteria harmful algal blooms
- JCLC — Jody Connor Limnology Center at NHDES
- DWGB – NHDES Drinking Water and Groundwater Bureau
- PWS – public water system
- USEPA – United State Environmental Protection Agency
- bloom – source water where the suspected bloom appears to be at its worst
- open water – an area of the lake or reservoir between the visible BLOOM and the intake
- raw – raw water entering the treatment plant
- finished – finished water entering the distribution system
- ELISA – enzyme-linked immunosorbent assay (Quantiplate) test for total Microcystins (ADDA) (modified USEPA method 546)
- LC/MS – Liquid Chromatography/Mass Spectrometry for analysis of specific Microcystins, Nodularin, Anatoxin-a, and Cylindrospermopsin (EPA Methods 544 and 545)
- BMAA – beta-Methylamino-L-alanine
- DABA – 2,4-diaminobutyric acid dihydrochloride
- Microcystins – (MC)
- Nodularins – (NOD)
- CMC – Cyanobacteria Monitoring Collaborative
- HDPE – high density polyethylene
- mL – milliliter
- PTFE – polytetrafluoroethylene


# MONITORING

1. **All public water systems (PWSs) using surface sources are advised to conduct at a minimum, daily visual surveillance** of their source water(s).
2. NHDES recommends that PWSs using sources with a history of suspected cyanobacterial blooms implement monitoring programs that incorporate continuous or frequent monitoring of source water or raw water for:
  - a. Phycocyanin
  - b. chlorophyll-a
  - c. pH
  - d. Temperature
  - e. Turbidity
  - f. Daily observation of weather conditions
3. To facilitate easy monitoring NHDES recommends:
  - a. Have sample bottles on hand prepared by JCLC.
  - b. Have samples bottles on hand prepared another lab following their specific protocol.
4. **When there are visual signs of a bloom** or water quality parameters (e.g., pH, turbidity, taste/odor) indicating a suspected cyanoHABs, the PWS should contact JCLC and the JCLC will notify DWGB of the confirmed bloom.
5. **Take samples of the bloom, open water, raw, and finished water in brown, 125 – 500 mL HDPE bottles supplied by JCLC.** Refer to “Sample Collection, Preservation, Shipment, and Storage” beginning on page 10. (When the PWS brings samples to JCLC for analysis, they will be provided with another set of sample bottles.)
6. **JCLC will visually identify and determine the density of cyanobacteria in the samples.** Based on the cyanobacterial cell counts, JCLC staff will consult with DWGB and determine whether toxin analyses should be done right away (or batched for later) and whether additional sampling should be done, either by the PWS or by NHDES.
7. If immediate action, such as treatment adjustments is required, DWGB will contact the PWS.
8. If toxin producing cyanobacteria are identified and in concentrations above 70,000 cells/mL, JCLC will make the appropriate decision as to which of the available toxin testing option(s) seem(s) appropriate (See Tables 1 and 2 for cyanobacteria and associated toxins). If a decision is made to use LC/MS methods, JCLC will first consult with DWGB, and then the PWS to run such tests and in what frequency.

**Toxin analyses may be done by the JCLC (ELISA for total Microcystin) and/or one of the labs that can conduct additional toxin testing (LC/MS methods for specific cyanotoxins).** Depending on the results, DWGB may ask the PWS to continue to sample water, will work with the PWS to optimize treatment, and will consider asking the PWS to **issue an advisory**. [Public notification templates are available.](#)
9. The PWS will notify DWGB once the required action(s) have been completed.

For more information on cyanobacteria and what they might look like, refer to [Cyanos.org](http://Cyanos.org)

# CyanoHABs Monitoring and Response Flowchart



## Table 1: Common New Hampshire Cyanobacteria and Associated or Known Toxins

The toxin test that NHDES may advise is first based on the presence of potentially toxic cyanobacteria, then on the concentration of cells (currently 70,000 cells/mL), and the type of toxin they may produce. JCLC will test by ELISA for total Microcystins/Nodularins and Anatoxin-a and/or a lab listed in Table 3 can test by LC/MS methods to determine 7 variants of Microcystins, Nodularins, Anatoxin-a, and Cylindrospermopsin. This is not a complete list of the cyanobacteria or the cyanotoxins.

Common Cyanobacteria Genera of New Hampshire	Typical Form Observed	Associated or Known Toxins
<i>Anabaena/Dolichospermum</i>	Filaments	Microcystins, Anatoxin-a, Anatoxin-a (S), Saxitoxins, Cylindrospermopsin
<i>Anabaenopsis</i>	Filaments	Microcystins
<i>Aphanizomenon</i>	Rafts of Filaments	Anatoxin-a, Anatoxin-a (S), Saxitoxins, Possibly Microcystins
<i>Aphanocapsa/Aphanothece</i>	Colonies or Single Cells	Microcystins
<i>Coelosphaerium</i>	Colonies	Microcystins
<i>Chroococcus/Gloeocapsa</i>	Colonies	Possibly Microcystins
<i>Gloeotrichia</i>	Macroscopic Colonies	Microcystins
<i>Lyngbya/Phormidium</i>	Benthic Filaments	Microcystins, Lyngbyatoxins, Anatoxin-a
<i>Merismopedia</i>	Rafts of Colonies	Microcystins
<i>Microcystis</i>	Variations of Colonies	Microcystins, Anatoxin-a
<i>Nostoc</i>	Macroscopic Colonies	Microcystins, Nodularins
<i>Oscillatoria/Planktothrix</i>	Filaments	Microcystins, Cylindrospermopsin
<i>Spirulina</i>	Filaments	Microcystins
<i>Synechococcus/Synechocystis</i>	Single Cells, Rarely Colonial	Microcystins and Saxitoxins
<i>Woronichinia</i>	Dense Colonies	Microcystins
<b>Note:</b> <ul style="list-style-type: none"> <li>Some genera grouped here have variations in their taxonomic name or are similar in morphology.</li> <li>Species may vary significantly. This is not a complete list of the cyanobacteria.</li> <li>More than one type of cyanobacteria and toxin may exist in a typical bloom.</li> <li>Microcystins are the most common cyanotoxin in New Hampshire and New England.</li> <li>Associated toxins are typical and may change as research evolves.</li> <li>Production of some toxins is “turned on” by genetic regulation.</li> <li>Toxin tests are also available for Nodularins, commonly produced by marine/brackish cyanobacterium called <i>Nodularia</i> (uncommon to New England).</li> <li>BMAA, DABA toxins (neurotoxins) have been associated with nearly all cyanobacteria.</li> <li>Dermal-toxins, causing rashes on skin can occur with most cyanobacteria.</li> </ul>		
Table created by Amanda Murby McQuaid		

## Table 2: Cyanotoxins and Common Modes of Action

(modified from *Handbook of Cyanobacteria Monitoring and Cyanotoxin Analysis, First Ed. 2017*).

Cyanotoxin	Mode of action and/or symptoms
Microcystins (nearly 100 variants)	Hepatotoxic, targets the liver and digestive organs, tumor promoting, inhibition of protein phosphatases. Acute gastroenteritis, chronic tumor promotion.
Nodularins (similar in structure to Microcystins)	Similar to Microcystins, but not as toxic and common in brackish or marine systems.
Anatoxin-a	Neurotoxic, inhibits acetylcholine receptors (neurotransmitter). Fast-acting and may cause seizures or death (i.e. common for dogs or other animals to ingest and die).
Anatoxin-a (S)	Neurotoxic, similar to anatoxin-a
Saxitoxins	Neurotoxic, blocking voltage gate of sodium ion channels. More common to marine organisms.
Cylindrospermopsins	Toxic to multiple organs, neurotoxic and genotoxic, affecting neurons and genes.
Lyngbyatoxins	Tumor promotion
BMAA/DABA	Neurotoxic, chronic exposure may be linked to neurodegenerative diseases such as ALS. (Though individuals may have a genetic precursor).
<b>Note:</b> <ul style="list-style-type: none"> <li>• Dermal-toxins, causing rashes on skin, and can occur with most cyanobacteria. Usually depends on the individual in contact.</li> <li>• Synergistic effects of the cyanotoxins may also occur.</li> <li>• Many of the cyanotoxins cause gastroenteritis-like symptoms, while others may cause seizure-like or possibly neurodegenerative symptoms.</li> <li>• Exposure can occur through drinking, food, dietary supplements, inhalation, and/or by dermal contact, and has occurred by hemodialysis (with contaminated water).</li> </ul>	

Table created by Amanda Murby McQuaid

# LABORATORY METHODS

## USEPA Methods for Cyanobacteria Toxin Analysis

USEPA Method 544: Determination of Microcystins and Nodularin in Drinking Water by Solid Phase Extraction and Liquid Chromatography/Tandem Mass Spectrometry (LC/MS/MS)

**JCLC does not perform this analysis. See Table 3.**

- Analytical method to determine six microcystins (including MC-LR) and nodularin in finished drinking water

USEPA Method 545: Determination of Cylindrospermopsin and Anatoxin-a in Drinking Water by Liquid Chromatography Electrospray Ionization Tandem Mass Spectrometry (LC/ESI—MS/MS)

**JCLC does not perform this analysis. See Table 3.**

- Analytical method to determine cylindrospermopsin and anatoxin-a, in finished drinking water

USEPA Method 546: Determination of Total Microcystins and Nodularins in Drinking Water and Ambient Water by ADDA—Enzyme—Linked Immunosorbent Assay (ADDA—ELISA)

- Analytical method to determine “total” microcystins (MC) and nodularins (NOD) in finished drinking water



## Table 3: Labs Conducting LC/MS and ADDA–ELISA Toxin Analysis using USEPA Methods 544/545/546

The Rhode Island State Health Labs and Greenwater Labs have indicated they can conduct toxin testing in a two–to three–day turnaround time for properly submitted samples. Other labs listed by USEPA are available for similar services. Consult USEPA’s list of [Laboratories that Analyze for Cyanobacteria and Cyanotoxins](#).

RHODE ISLAND STATE HEALTH LABORATORIES*	Evan K. Philo Principal Lab Scientist/Food Testing Coordinator  <a href="tel:(401)222-5553">(401)–222–5553</a> <a href="mailto:Evan.Philos@health.ri.gov">Evan.Philos@health.ri.gov</a>	RI State Health Laboratories RI Dept. of Health 50 Orms Street Providence, RI 02904	Combined USEPA 544/545 Methods: \$250/sample  USEPA Method 546: \$50	<b>Sample Protocol:</b> Amber glass bottles**  Keep cold.  <b>Shipping Protocol:</b> Ship on ice
GREENWATER LABORATORIES*	<a href="tel:(386)328-0882">(386) 328–0882</a> <a href="http://Greenwaterlab.com">Greenwaterlab.com</a>	205 Zeagler Dr. Palatka, FL 32177	USEPA 545 Method: \$420/sample  USEPA 546 Method: \$240/sample  Shipping Cost: \$100  Lab <b>DOES NOT</b> do USEPA Method 544	<b>Sample Protocol:</b> Amber glass bottles**  Keep cold  <b>Shipping Protocol:</b> Ship on Ice
<p><b>* Call laboratory to confirm they can analyze the sample(s) prior to shipping.</b></p> <p><b>**Amber glass bottles and preservatives will be supplied upon request by DWGB. Contact:</b></p> <p>Liz Pelonzi, Source Protection Specialist at <a href="tel:(603)271-3906">(603) 271–3906</a>; <a href="mailto:ann.pelonzi@des.nh.gov">ann.pelonzi@des.nh.gov</a> Pierce Rigrod, Supervisor, Source Water Protection Program at <a href="tel:(603)271-0688">(603) 271–0688</a>; <a href="mailto:pierce.rigrod@des.nh.gov">pierce.rigrod@des.nh.gov</a></p>				

# SAMPLING

This sampling protocol outlines how to collect cyanobacteria and cyanotoxin samples at PWS source waters, finished waters, and other sampling locations. This protocol does not address sample collection for site specific monitoring plans. Consult with JCLC, Harmful Algal and Cyanobacterial Bloom Program, on recommendations for a routine cyanobacteria monitoring plan, or refer to USEPA Cyanobacteria Monitoring Collaborative (CMC) at [cyanos.org](https://cyanos.org).

## Safety Precautions

- Wear protective gear such as gloves if handling a suspected harmful cyanobacteria bloom.
- Precautions should be taken to avoid mouth and eye contact.
- Wear eye protection and a mask to further prevent exposure.
- Chest waders should be worn if collecting a cyanotoxin sample when wading off the shore to protect skin from contact with cyanotoxins.
- Always wash your hands and rinse thoroughly after handling.

## Recommended Safety Supplies

For cyanobacteria and cyanotoxin sampling at public water systems, the recommended safety supplies include:

- Disposable gloves or reusable arm-length gloves
- Goggles
- Mask
- Chest Waders

## General Sampling Supplies

Cooler with packed ice for sample storage under 12 hours and/or refrigerate if up to 24 hours until delivery. (Do not allow bottles to float in warm water or melted ice water)

High density polyethylene (HDPE) brown bottles of at least 125 mL capacity

## Analytical Method Specific Supplies

For cyanobacteria screening and toxin sampling for Microcystins/Nodularins at NHDES JCLC:

- HDPE brown bottles of at least 125 mL capacity.
- HDPE bottles will be supplied upon request by calling the Cyanobacterial Bloom Hotline at [\(603\) 848-8094](tel:6038488094).



For cyanobacteria toxin sampling for lab analysis using USEPA Methods 544/545 at Rhode Island Public Health Lab or Greenwater Lab:

- 500-mL amber glass bottles (1–2) fitted with polytetrafluoroethylene (PTFE)–lined screw caps and USEPA Method specific preservatives.
- Amber glass bottles and preservatives will be supplied upon request by DWGB, contact:
  - Liz Pelonzi, Source Protection Specialist at [\(603\) 271–3906](tel:6032713906) or [ann.pelonzi@des.nh.gov](mailto:ann.pelonzi@des.nh.gov)
  - Pierce Rigrod, Supervisor, Source Water Protection Program at [\(603\) 271–0688](tel:6032710688) or [pierce.rigrod@des.nh.gov](mailto:pierce.rigrod@des.nh.gov)



## Sample Collection, Preservation, Shipment and Storage

### Sample Collection Procedure for Grab Samples and Surface Skim Samples

- **Grab samples:** samples that are collected from a sample tap or by submerging a bottle in water at an attainable location by hand. Wearing gloves, sample by submerging bottle slowly through the water and swing arm in a u-shaped orientation. Recommended for:
  - Water surface
  - Beach or shoreline at knee depth (or about 1 meter)
  - Raw or finished water (from a sample tap)
- **Surface skim:** using a collection bottle to skim the surface of the water. Recommended for:
  - Dense surface bloom or shoreline accumulation

### Sample Collection Procedure for EPA Methods 544 and 545

- Open the cold water tap and allow the system to flush until the water temperature has stabilized (approximately 3 to 5 minutes). Collect samples from the flowing system. Fill sample bottles, taking care not to flush out the sample preservation reagents.
- After collecting the sample, cap the bottle and agitate by hand until preservative is dissolved. Note that 2–chloroacetamide is slow to dissolve, especially in cold water. Samples must be chilled during shipment but should not be frozen.
- Shipping instructions are provided in [Table 3](#).

### Sample Collection Procedure for EPA Method 546

- Open the tap and allow the system to flush for approximately 5 minutes. Fill each bottle, taking care not to flush out the sodium thiosulfate. Invert bottle(s) several times to mix the sample with the reducing agent. Sample must be chilled during shipment but should not be frozen.
- Shipping instructions are provided in [Table 3](#).

## JCLC Sample Submittal Procedure

Samples will be analyzed free of charge. At JCLC samples may be analyzed for:

- Cyanobacteria ID and cell count
- Microcystins/Nodularins by ELISA methods (1–2–day turnaround)

1. Take a photo(s) of the bloom and submit it to Harmful Algal and Cyanobacterial Bloom Program Coordinator at JCLC ([HAB@des.nh.gov](mailto:HAB@des.nh.gov))
2. Collect a sample(s) from the options listed below, using a 125mL brown HDPE bottle(s). Bottles will be supplied by
  - a. Grab sample
  - b. Surface skim

*\*Avoid collecting samples from areas where the bottom sediment has been disturbed.*
3. Label and store water samples properly
  - a. Label 125 mL brown HDPE bottle(s) to include:
    - i. Waterbody and location (coordinates if possible)
      1. Bloom
      2. Open water (away from bloom)
      3. Intake, Raw water
      4. Finished water
      5. Or other location within source
    - ii. Date and time
    - iii. Type of sample (indicate if this was a surface bloom or other)
    - iv. How sample was stored (e.g. on ice, frozen, refrigerated, no preservative) **DO NOT FREEZE for cell count and identification.**
4. Place in packed ice in cooler (if delivering within 12 hours of event) or freeze sample (if storage on ice or refrigeration will be longer than 24 hours) until delivery to JCLC.
  - a. **Avoid filling to the top to allow for freezing expansion. If sample will be frozen, only fill to about 2/3<sup>rd</sup> of bottle or to the neck.**
  - b. Bring samples to JCLC, 29 Hazen Dr., Concord, NH during business hours (8:00 a.m.–4:00 p.m.) or by prior arrangement.
5. When dropping off the sample(s), fill out a requisition form at the JCLC for confirmation of sample delivery and details of bloom event with appropriate contacts.
  - a. Your name, contact and concern
  - b. Location – waterbody, beach or specific bloom area or depth
  - c. Date, time and weather
  - d. Details or description of bloom– surface scum or throughout water column, surface area, magnitude of area, color and odors, etc.
  - e. Submit photos if possible to [HAB@des.nh.gov](mailto:HAB@des.nh.gov)
  - f. How sample was collected and stored prior to delivery

If additional toxin analysis for Microcystins, Nodularin, Cylindrospermopsin and Anatoxin-a using USEPA Methods 544, 545, or 546 is required, DWGB will request the system take additional samples. Laboratories that conduct these methods are listed in [Table 3](#) above.

If using USEPA Methods, follow USEPA [sampling procedure](#) instructions.

NH Department of Environmental Services  
Drinking Water and Groundwater Bureau  
29 Hazen Drive, PO Box 95  
Concord, New Hampshire 03302-0095  
[\(603\)-271-2513](tel:(603)-271-2513)

[www.des.nh.gov](http://www.des.nh.gov)